

# Wind Wavers™ Drop and Sail Installation Instructions

## Step 1:

Remove all parts from cases. Separate all pieces. Number of pole pieces may vary depending on pole size.



Stackable Sectional Poles



Ground Screw  
& Metal Arm



Drop or Sail flag

## Step 2:

First, remove rubber cap from the bottom of the pole. After removing the pole sections, remove the cap from the top of the pole. Retain ALL CAPS for future use. Assemble poles by placing smaller end into larger end.



**NOTE: This is a stackable pole. It is NOT a telescoping pole**



## Step 3:


Place metal arm in the hole on the ground screw and turn clock-wise to screw ground screw into the ground.



## Step 4:

Slide pole into sleeve of flag and hold firmly.

**NOTE:** Be certain the tip of the pole is fully inserted into the strengthened **TOP END** of the sleeve.



## Step 5:

While holding firmly on the pole, place bottom end of the pole on swivel. Pull clip down and hook into ring on the ground screw to secure the flag to the ground screw.

**Caution:**  
**DO NOT install or fly flags in winds over 20 mph.**  
Any questions call  
**1-800-837-6306**  
**Monday - Friday**  
**8:00 am to 5:00 pm EST**



Completed Wind Wavers™ Drop & Sail